



BREAKER OF MINIMUM:
 1 1/2" REDWOOD,
 1 1/2" .40 ACQ
 PRESSURE TREATED OR
 2" SLAB FOAM INSULATION

VAPOR BARRIER:
 6 MIL POLYETHYLENE OR
 30 LBS. ASPHALT FELT OR
 HOT ASPHALT

4" CONCRETE FLOOR
 4" FOAM INSULATION
 MINIMUM AGED R-VALUE
 TO BE 5.0 PER INCH
 MIN. 4" CONCRETE
 SUB-SLAB

FEMALE BOTTOM RAILS ON TOP OF AN INSULATED FLOOR

DETAIL 011E
 DRAWN 9/5/95
 REVISED 7/17/02



©2020 Nor-Lake, Inc. All rights reserved.