

NORLAKE<sup>®</sup>

## KOLD LOCKER™ Walk-In Coolers & Freezers

*Designed for easy  
installation with matching  
Capsule Pak™ or  
Capsule Pak ECO™  
refrigeration systems.*

### Features

- Available from 4' x 6' to 10' x 14'
- Available in 3 heights: 6'7" & 7'7" with floor, 7'4" less floor
- Capsule Pak or Capsule Pak ECO refrigeration system featuring a flush coil to allow 100% usable interior space
- Temperatures: +37°F and -10°F
- Indoor and outdoor cooler or freezer models
- Spring actuated door closer
- Exterior finish is corrosion resistant stucco embossed coated steel
- Full 4" panel foamed-in-place with EPA-compliant polyurethane insulation
- Deadbolt locking handle for security
- Adjustable spring loaded door hinge
- High output low profile LED light positioned above door to prevent interference with shelving or product
- 15 year panel warranty



## Options

- Condensing unit air deflector kit on outdoor models
- Exterior ramp
- Floor tread kickplate kit
- Heater kit for cooler located outdoors in below +32°F ambient
- Heights: 6'7" & 7'7" with floor, 7'4" less floor
- 8'7" and 8'4" heights available in models up to 8' x 14' size (with restrictions)
- Leak detector/alarm (may be a requirement in some areas)
- Additional LED lighting
- 5 year compressor warranty
- Specially designed shelving kits
  - Flexible shelf adjustment in 1" increments
  - Shelving layouts utilize maximum space for storage leaving the door opening clear of end standards
  - Green Kote™ special epoxy-coated finish provides extra protection from acidic foods
  - Quick and easy assembly
  - Rigid construction
  - Optional U-shaped systems



Door & frame kickplates add protection to your entry doors (shipped loose).



Exterior ramps make it easy to roll items directly into your walk-in.



Optional shelving kits allow you to utilize more of the space available in your Kold Locker™ walk-in.

## CAPSULE PAK™ & CAPSULE PAK ECO™ REFRIGERATION SYSTEMS



**CAPSULE PAK**  
INDOOR & OUTDOOR MODELS



**R-449A**  
ECO-FRIENDLY  
REFRIGERANT

Designed for simple and fast installation, Capsule Pak and Capsule Pak ECO self-contained systems consist of a condensing unit and evaporator coil contained in a single housing.



Standard LogiTemp® electronic controller on Capsule Pak and Capsule Pak ECO systems for increased reliability.



**CAPSULE PAK ECO**  
INDOOR MODELS ONLY



**R290**  
ECO-FRIENDLY  
NATURAL REFRIGERANT



**PATENT  
PENDING  
DESIGN**



891 County Road U • Hudson, WI 54016  
800-955-5253 • www.norlake.com



Revision Date: 5/23  
Part Number: 101624



All specifications within this publication subject to change without notice. ©2023 Norlake, Inc. All rights reserved.