



FINELINE™ WALK-INS

Custom
designed
to meet any
requirements



FEATURES

- Cooler, freezer or combination cooler/freezer models, multiple compartments and warehouse buildings
- Glass doors or special doors
- Specify any size
- Specify any shape or angle
- Specify any height
- Specify any color
- Specify exterior metal finish
- Specify interior finish
- NL2400 adjustable spring loaded hinge
- Spring actuated door closer
- Digital thermometer and light switch
- Standard deadbolt locking handle
- Kickplate
- 15 year panel warranty – industry leading
- Approvals:
 - NSF
 - UL flame spread 25 or less for foam cores
 - UL and CSA electrical door section
 - City of Houston
 - Oregon State
 - State of Wisconsin Building Product
 - USDA accepted
 - Miami-Dade County, Florida
Approval No. 19-0911.03, Exp. 05/10/2023
(Consult factory for requirements)
 - State of Florida Product Approval
File No. FL28473-R1
(Consult factory for requirements)

800-955-5253 | norlake.com

OPTIONS

- Bumper rails, trim strips and closure panels
- Cooler and freezer door viewports
- Extra lights and special switches
- Indoor and outdoor roof and ceiling support systems
- Interior and exterior door kickplates
- Interior and exterior ramps
- LED Lighting
- Selection of interior and exterior surfaces and finishes
- Special floor underlayments and topside plating
- Various door styles and sizes
- Various security alarm systems
- Wide range of computer sized and balanced refrigeration systems
- Specially designed shelving kits
 - Flexible shelf adjustment in 1" increments
 - Shelving layouts utilize maximum space for storage leaving the door opening clear of end standards
 - Green Kote™ special epoxy-coated finish provides extra protection from acidic foods
 - Quick and easy assembly
 - Rigid construction
 - Stronger shelves
 - Optional U-shaped systems

SPLIT-PAK™ REMOTE REFRIGERATION SYSTEMS*

- Systems composed of condensing unit and evaporator coil sized to fit requirements
- All components are pre-wired and factory assembled on a galvanized steel angle leg base
- Condensing units are provided with factory pre-mounted and wired time clocks in both medium and low temp versions
- Evaporator coils are ready to mount in position and are available in air (off cycle) defrost for coolers and electric defrost for freezers
- Each coil is also furnished with a pre-installed expansion valve and room thermostat mounted and wired
- Electric defrost coils feature defrost termination-fan delay controls and drain line heaters
- Standard energy efficient EC motors

*Limited models stocked



Dedicated medium temp condensing units meet the DOE requirement of a minimum AWEF rating of 5.61 (Btu/W-h) for indoor models and 7.6 for outdoor models.



727 Second Street | Hudson, WI 54016
800-955-5253 | 715-386-6149 FAX
www.norlake.com



Revision Date: 12/20
Part Number: 101626

All specifications subject to change without notice.
©2020 Nor-Lake, Inc. All rights reserved.