

NORLAKE®

MILK COOLERS



Single and dual access models in white or optional stainless steel finish

FEATURES

- Three sizes available in either single or dual access
- Choice of white enamel exterior or optional stainless steel
- Stainless steel interior
- Self-service locking stainless steel doors interior and exterior
- Door "hold open" feature secures doors during serving
- Designed with a powerful refrigeration system to maintain product temperature for longer periods of time with the doors open
- Electronic control system with digital thermometer for added reliability
- Corner bumpers for damage protection
- Interior drain for easy cleaning
- Heavy-duty casters for mobility
- Epoxy coated heavy-duty floor racks
- ETL Safety & Sanitation listed
- Three-year parts and labor & five-year compressor warranty

COLD WALL EVAPORATOR REFRIGERATION SYSTEMS

- More storage space as no evaporator coil is installed inside the cooler
- Superior energy efficiency over systems containing an evaporator coil
- Fewer mechanical parts for longer service life
- Better temperature maintenance in high humidity environments

800-955-5253 | norlake.com

SPECIFICATIONS

Model	Cases With Cartons				Loose Cartons (Without Cases)			
	13" x 13" x 11"H		19" x 13" x 11"H		Flat Top		Peaked Top (Gable)	
	Cases	Cartons	Cases	Cartons	1/2 Pint	1 Pint	1/2 Pint	1 Pint
NLMC08S single access	8	352	4	288	864	432	680	430
NLMC08D dual access								
NLMC12S single access	12	528	8	576	1368	684	1020	645
NLMC12D dual access								
NLMC16S single access	16	704	10	720	1800	900	1360	860
NLMC16D dual access								

Model*	NLMC08S* single access/ NLMC08D* dual access	NLMC12S* single access/ NLMC12D* dual access	NLMC16S* single access/ NLMC16D* dual access
Crated Weight (lbs.) (kg)	165 (75)	212 (96)	243 (110)
Overall Height (in) (cm)	42 (107)	42 (107)	42 (107)
Overall Width (in) (cm)	34 (86)	49 (124)	58 (147)
Overall Depth (in) (cm)	30.6 (78)	30.6 (78)	30.6 (78)
Gross Cubage (CuFt) (L)	13.2 (374)	19.6 (555)	23.5 (665)
Number of Floor Racks	2	2	2
Number of Casters	4	4	4
Condensing Unit Size (HP)	1/4	1/4	1/4
Refrigerant	R290	R290	R290
Electrical Characteristics	115/60/1	115/60/1	115/60/1
Cord and Plug Furnished	Yes	Yes	Yes
Nema Plug Configuration	5-15P	5-15P	5-15P
Total Amp Draw	3.0	3.0	3.0

* Add suffix "W" for white exterior, "S" for stainless steel.



727 Second Street | Hudson, WI 54016
800-955-5253 | 715-386-6149 FAX
www.norlake.com



Revision Date: 8/20
Part Number: 101860

