



## FAST-TRAK® WALK-INS



### FEATURES

- Available in widths of: 6', 7' & 8'
- Unlimited lengths in 1' increments
- Heights: 7'7" & 8'7" with floor, 7'4" & 8'4" floorless
- Coolers, freezers or combination cooler/freezers
- Exterior finish is corrosion resistant stucco embossed coated steel
- Full 4" panel foamed-in-place with HFC free HFO polyurethane insulation
- Indoor or outdoor models
- Fast and easy installation
- 30" or 36" self-closing door
- Digital thermometer and light switch
- NL2400 adjustable spring loaded hinge
- Spring actuated door closer
- Deadbolt locking handle for security
- Pre-assembled remote refrigeration systems in stock for 5 day shipment
- Temperatures: +38°F, +35°F, -10°F
- 15 year panel warranty - Industry leading
- Approvals:
  - NSF listed
  - UL flame spread of 25 or less
  - ULC listed flame spread
  - UL and CSA electrical listing on door sections
  - City of Houston listed
  - California State listed
  - Oregon State listed
  - USDA accepted

800-955-5253 | [norlake.com](http://norlake.com)

# OPTIONS

- 9', 10', 11' & 12' width\*
- Aluminum diamond tread or stainless steel interior and exterior kickplates
- With floor/less floor combination\*
- Exterior ramp (with floor models)
- Interior ramp\*
- Non-skid strips (shipped loose)
- Extra vapor-proof lights (shipped loose)
- LED Lighting
- Outdoor membrane roof systems
- Secure Guard™ locking system (factory installed)
- Viewport
- Strip curtains (shipped loose)

\*Available with 10-day shipment

- Door rain hoods
- Indoor remote refrigeration system
- Specially designed shelving kits
  - Flexible shelf adjustment in 1" increments
  - Shelving layouts utilize maximum space for storage leaving the door opening clear of end standards
  - Green Kote™ special epoxy-coated finish provides extra protection from acidic foods
  - Quick and easy assembly
  - Rigid construction
  - Stronger shelves
  - Optional U-shaped systems

## SPLIT-PAK™ PRE-ASSEMBLED REMOTE REFRIGERATION SYSTEMS

Indoor Split-Pak condensing unit



Outdoor Split-Pak condensing unit



- All condensing units are assembled on a heavy-duty platform
- Balanced remote refrigeration systems
- Most models in stock for 5-day shipment
- Pre-charged systems include quick connect fittings for easy installation

- Systems include an all weather hood and outdoor controls for -20°F ambient installations
- May be ordered uncharged for field installation or pre-charged with pre-charged line lengths from 5' to 50' with quick disconnects for easy installation
- Timed defrost on cooler and freezer systems

Dedicated medium temp condensing units meet the DOE requirement of a minimum AWEF rating of 5.61 (Btu/W-h) for indoor models and 7.6 for outdoor models.



727 Second Street | Hudson, WI 54016  
800-955-5253 | 715-386-6149 FAX  
www.norlake.com



Revision Date: 2/20  
Part Number: 101625