



CAPSULE PAK™ & CAPSULE PAK ECO™ Refrigeration Systems

*Built for easy installation
and efficient operation.*

SYSTEM GUIDE

Capsule Pak™ Self-Contained Systems



One-piece packaged systems with condensing unit and evaporator coil in a single housing. Available in indoor and outdoor models.



R-449A
ECO-FRIENDLY
REFRIGERANT

Capsule Pak™ Remote Systems

Indoor and outdoor remote refrigeration systems consisting of a separate evaporator coil and condensing unit which are quick-connected using pre-charged refrigerant line sets.



R-449A
ECO-FRIENDLY
REFRIGERANT



Evaporator section
located on top of walk-in.

Condensing unit section
remotely located.

Capsule Pak ECO™ Systems



Built for maximum sustainability and energy efficiency with a significantly reduced Global Warming Potential of 3, these one-piece indoor systems also take up less space.



R290
ECO-FRIENDLY
NATURAL REFRIGERANT



**PATENT
PENDING
DESIGN**

SYSTEM FEATURES



Flush mounted evaporator coil in the walk-in ceiling panel for maximum interior storage space.



Standard LogiTemp® electronic controller increases refrigeration system reliability and food safety.



Standard 115V cord and plug eliminating the need for field electrical connection (not applicable on remote models).

FEATURE	1-PIECE SELF-CONTAINED CAPSULE PAK WITH R449A	2-PIECE CAPSULE PAK REMOTE WITH R449A	CAPSULE PAK ECO WITH R290
Indoor and outdoor models	✓	✓	Indoor Only
Available for coolers (+37°F) or freezers (-10°F)	✓	✓	✓
Pre-charged with refrigerant eliminating the need for field refrigeration connection	✓	⊗	✓
Remote system with pre-charged line sets	⊗	✓	⊗
Designed to operate in ambient temperatures up to 100°F	✓	✓	✓
Air cooled condensing unit	✓	✓	✓
Automatic condensate evaporator (indoor models only)	✓	⊗	✓
Electronic control provided for automatic defrost on both coolers and freezers	✓	✓	✓
UL and C-UL electrical listing on complete refrigeration systems*	✓	✓	✓
AWEF compliant	✓	✓	✓
DOE, CARB and SNAP compliant	✓	✓	✓
-20°F ambient controls (outdoor models)	✓	✓	⊗
Systems for outdoor walk-ins contain a crankcase heater and head master	✓	✓	⊗
18 months parts and labor warranty	✓	✓	✓
Patent pending design	⊗	⊗	✓
Optional electric vaporizer (indoor models only)	✓	✓	✓
Optional condensing unit air deflection kit	✓	✓	✓
Optional lengths of pre-charged refrigerant lines	⊗	✓	⊗
Optional wiring harness	⊗	✓	⊗
Optional 5 year compressor warranty	✓	✓	✓

* C-UL is Underwriters Laboratories Safety Certification Mark which indicates that UL has tested the equipment to applicable CSA Standards.



891 County Road U • Hudson, WI 54016
800-955-5253 • www.norlake.com



All specifications within this publication subject to change without notice. ©2023 Norlake, Inc. All rights reserved.

Revision Date: 5/23
Part Number: 171574