

NORLAKE®



THERMOMETER & LIGHT MANAGEMENT SOLUTIONS

For Walk-In
Coolers & Freezers

*Increase food safety,
efficiency and energy
savings.*

Standard NL508 Thermometer & Light Switch

- Standard feature on all Norlake walk-ins
- Light switch and digital thermometer combined in one component
- Indoor or outdoor installation
- LED Temperature display with °F/°C capability
- Light switch and cover
- Waterproof “elbow-engaged” illuminated light switch allows operators to turn on light easily, even with hands full
- 120 volt, 15 amp direct power
- 1 minute or 3 minute display update
- Digital display easy to read in all ambient conditions
- -40°F to +230°F range
- UL, NSF, C-UL, CE approvals/listings
- Optional battery back-up and 230 volt electrical



1. Alarm Cancel
2. Low Temp Alarm Setting
3. High Temp Alarm Setting
4. Programming Keys
5. Light Switch With Auto Off

Optional NL 708 Alarm & Light Management System

- Leaving doors open and inside lights on are the two biggest energy wasters in walk-ins. Open doors can also compromise food safety. The NL708 system provides alarms and light management to solve these problems.
- -40°F to +230°F range
- Hi/low temperature alarms with delays
- Light management:
 - Turn light on at keypad
 - Light timer for automatic shut off
- Easy to set alarms



Optional wall mount box with external buzzer and automatic light switch

Optional Packages

- Wall mount box with external 85db pulsing buzzer
- Door open alarm and automatic light switch
- Remote phone dialer
 - 2 circuit phone dialer
 - 2 channel digital input
 - 4 programmable phone numbers for each channel
- Occupancy sensor for light operation and panic alarm
- Extended temperature sensor 30'
- Remote buzzer box
- Field retrofit option – all door styles



891 County Road • U Hudson, WI 54016
800-955-5253 • norlake.com



Revision Date: 10/21
Part Number: 139586



All specifications within this publication subject to change without notice. ©2021 Norlake, Inc. All rights reserved.